

Engine Oil Pan Skid Plate Installation Guide

On the Rox Fabrication

Ontheroxfab.com

406-967-2189



***READ INSTRUCTIONS THOROUGHLY BEFORE BEGINNING. OTR IS NOT RESPONSIBLE FOR INCORRECT INSTALLATION OR LOCAL LAWS REGARDING AFTERMARKET ACCESSORIES. THE USER IS RESPONSIBLE FOR ALL LIABILITIES ASSOCIATED WITH THE INSTALLATION AND USE OF THIS PRODUCT.**

ALWAYS UTILIZE PERSONAL SAFETY EQUIPMENT WHEN YOU ARE WORKING IN THE SHOP.

Tools Needed:

- 24mm Wrench
- 19mm Wrench
- 15mm Wrench



Step 1: Assemble skid plate components as pictured below. With the oil pan drain hole towards you assemble left and right plate using supplied 12mm bolts, washers, and nuts. (DO NOT tighten all the way yet)



Step 2: Remove front bottom motor mount bolts from both sides of engine.



Step 3: Hold the assembly into position and use the supplied 12mm bolts for the front mount, the 10mm bolt got the rear left and the 16mm bolt for the rear right.

