

Winch Plate Installation Guide

On the Rox Fabrication

Ontheroxfab.com

406-967-2189



*READ INSTRUCTIONS THOROUGHLY BEFORE BEGINNING. OTR IS NOT RESPONSIBLE FOR INCORRECT INSTALLATION OR LOCAL LAWS REGARDING AFTERMARKET ACCESSORIES. THE USER IS RESPONSIBLE FOR ALL LIABILITIES ASSOCIATED WITH THE INSTALLATION AND USE OF THIS PRODUCT. ALWAYS UTILIZE PERSONAL SAFETY EQUIPMENT WHEN YOU ARE WORKING IN THE SHOP.

- Begin by removing front bumper and factory blank panel.



- Align winch plate to the holes.



- Using a $\frac{3}{4}$ " box end wrench, insert a nut into the frame. Repeat on other side rear hole, tighten before moving on. Bolts can be tightened to 100 ft-lbs.



- Install front bolts and tighten to 100 ft-lbs. Grommet goes on left side hole.

